

R1 SPLITTER FOR 07'-13' INSTALLATION

Tools needed:

1. 7/32" Hex Bit Socket
2. Drill
3. 15mm Socket/Wrench

What's in the Box:

1. Splitter Plate
2. Brackets
3. Bolts
4. Drill Bit

Steps

1. Remove the 2 bolts that hold the Fog light bracket (15mm).



2. On the Driver Side, this bolt must be removed to allow the bracket to slide behind the plastic cover



3. Install the hangers with the long vertical part up against the frame.
4. Before tightening down the bolts, ensure that the bottom of the hanger is level with the ground and that it is at the same height as the bottom of the bumper.
5. Bolt the splitter plate up to the hangers using the 4 Button Socket Screws and washers provided.
6. Adjust the location of the splitter by pulling it in or out to best suit your situation. Once you got it where you want it, tighten down all for bolts.

7. Installing the adjustable rods: The location for these will be up to you. You will need to use the drill bit provided to drill the holes for the rods to bolt on to. Make sure to use the washer provided on the underside of the splitter.
8. Make sure to check that the splitter is not loose every now and then. Give it a small kick to see if rattles or moves.